

PILLAR MOUNT

INSTALLATION FOR:

FORD 99-02

Part # F-130100

Note: The pillar mount only comes in black due to different interior colors. It is recommended to go to a ford dealer to get a paint that will match your truck.

TOOLS NEEDED:

No Tools Required.

1 You will need to start by removing the weather seal that runs around the door frame. Only remove the portion located by the pillar. (see figure 1.)

2 Now you can start to install the Commander mount to the pillar in your truck.

3 You will want to run the Commander cable through the pillar and down the back of the dash before putting the mount on the pillar. The cable should run between the mount and the factory pillar.

4 Once you have pushed the mount into place you can then push the weather seal back onto the door frame. In most cases you should not need anything else to hold the mount in place, it should lock into place pretty tight.

5 We have supplied some double sided tape in case you feel it is needed.



Figure 1

