



# PILLAR MOUNT FOR THE COMMANDER

## INSTALLATION

- 1** Remove the bolt at the bottom of the handle on your factory pillar. You will have to use a small flat head screw driver or you finger nail to remove the plug over the screw to do this.
- 2** Peel down the factory weather seal on the door frame from the top of the pillar to the bottom. This will allow you to place the aftermarket pillar over the factory one with a very clean look.
- 3** Before continuing on to the next step you will need to find a box knife or a razor blade and remove the two pieces of plastic on the back of the Commander that the original mount attached to.
- 4** You will need to run the commander through the pillar mount before attaching it to the factory pillar. We recommend that you do not attach the commander to the pillar mount until it is all in place. You will run the cable down the pillar and out under the dash so you can attach it to its harness.
- 5** Now place your commander pillar mount over the factory one. Line the hole in the Commander pillar mount up with the hole in the factory pillar and place the bolt that was supplied with your kit through the holes and tighten. (Do not use the factory bolt.)
- 6** Once you have the mount installed then you can reattach the weather seal to the door frame and attach your commander to the mount by removing the plastic off of the Velcro that is already attached to your pillar mount.



Part#: D-130105