

### Analog Display Instructions

- 1) Connect the included 12-in. 3-wire cable to the back of the gauge as follows: red wire to pin #2, black wire to pin #4, and green wire to pin #5.
- 2) Connect either of the LM-1 analog outputs to input #2 of the gauge (red wire). The Innovate Analog Output Cable is wired as follows: Red is LM-1 output #1, and White is output #2.
- 3) Connect the LM-1 Ground (copper shield wire on analog output cable) to gauge input #5 (green wire).
- 4) Connect gauge input #4 to ignition 12V (or other switched 12V supply).
- 5) Program the appropriate LM-1 analog output as follows: 1V=8AFR (.544  $\lambda$ ) and .0V=18AFR (1.224  $\lambda$ ). The analog display will now precisely display the analog output of your LM-1.

